



Starpatch Concrete Products

#5 –6420 Beresford Street,
Burnaby, B.C. V5E 1B6
Phone: (604) 433-7355 Fax: (604) 433-7358

Patching Product Maintenance Guide

**Starpatch Concrete Products
Repair Product Maintenance Guide**

This following guide is intended as a “general” guide to outline basic maintenance tips to prolong the life of Starpatch Concrete repair products. Please note the key to longevity for any repair topping is the quality of the installation. Always follow surface preparation, mixing and application instructions outlined in the relevant product data sheet.

Maintenance tips:

- Starpatch Concrete repair toppings and anchoring grouts should be cleaned on an as needed basis. Please follow the same schedule that adjacent concrete surfaces require in the building.
- If cleaning with a pressure washer, avoid cleaning patches with extremely high pressures. Try to use 2000psi or less when pressure washing.
- If a sealer or coating is present – maintain the coating as required or according to the maintenance schedule outlined by the coating manufacturer.
- Avoid use of heavy acids for cleaning. Light acid washes can be tolerated, as can most non-acid cleaning agents.
- If no sealer is specified – consider applying a sealer. Preventing water in migration is the simplest way to reduce the effects of freeze/thaw damage.

In general, Starpatch Concrete repair products do not require special cleaning or maintenance that is any different than what would be done for normal concrete.